

Influence of moving and fixed cathodes on the vacuum arc

A. Lawall, N. Dorraki, F. Graskowski, S. Gortschakow






Content

1. Introduction
2. Experimental Setup
3. Results
4. Conclusion and Discussion

Introduction

Vacuum Interrupter Design



1. Introduction

- Difference in spectra depending whether the cathode or anode has been moved
- Movement in horizontal direction
- CuCr Butt contacts
- Opening velocity $> 2\text{m/s}$





Figure 6: Spatially integrated optical emission spectra along the arc axis over time during the contact opening; top: moved anode, bottom: moved cathode.

R. Methling, T. Meyer, D. Uhrlandt, S. Gortschakow, M. Kurrat:
„Optical and spectroscopic analysis of vacuum arcs in larger gaps“; 31st Int. Symp. On Discharges and Electrical Insulation in Vacuum, Chengdu, China (2025)


1. Introduction

- Difference in erosion rate depending on movement of the electrode
- Movement in vertical direction
- Movable contact below
- CuCr butt contacts
- Opening velocity ≈ 1.3 m/s
- Polarities are equally mixed



1. Introduction

- Fixed polarity: Anode fixed contact, Cathode movable contact
- Movement in vertical direction
- Movable contact below
- CuCr butt contacts
- Opening velocity ≈ 1.3 m/s
- Higher burn-off rate when cathode is moved




1. Open Question

Why does it make a difference whether a contact is moved or not?

Are gravitational forces really playing a role?




2. Experimental Setup



- **High-speed video camera:**

- up to 100,000 frames/s
- typ. 400x100 pxl @ 25...50 kfps
- inclination to contact surface $\approx 20^\circ$




Drawing of AMF contact system and nearby current return conductor ("neighbor phase")

- 1: fixed AMF contact
- 2: moving AMF contact
- 3: current return conductor
- 4: arc / electrode region visible in high-speed videos
- 5: enlarged region of high-speed videos

3. Cathode

AMF cathode surface effects

- Diffuse (individual spots) and dense arcs exist simultaneously
- a thin surface layer of ca. 100 μm melts
- protrusions of $>\text{mm}$ grow rapidly, bearing bright cathode spots on their top
- at their end of life, the cathode protrusions release droplets while the cathode spots disappear



3. Anode

AMF contacts after contact separation

- anode response at high current density is remarkably different from that of the cathode:
- anode melting is smooth and without protrusion growth
- no mechanisms related to spots are found on the anode
- the anode remains passive, collecting charged and neutral particles only




3. What have we seen so far

- Diffused arc and partly diffused arc investigated
- Fundamental differences between cathode and anode as fixed contacts
- These differences can play a role concerning the movement of the electrodes
- No magnification of moving electrodes
- Axial magnetic field superimposed => Go back to butt contacts




FC: Anode, MC: Cathode

2.5 kA rms, 20000 fps (exposure: 10 μ s)




FC: Cathode, MC: Anode

2.5 kA rms, 20000 fps (exposure: 20 μ s)




FC: Anode, MC: Cathode

3.1 kA rms, 50000 fps (exposure: 2.5 μ s)





FC: Cathode, MC: Anode

3.1 kA rms, 50000 fps (exposure: 2.5 μ s)



Comparison of arc modes



Influence of moving and fixed cathodes on the vacuum arc

- With moving cathodes the regime of constricted arcs is considerably larger
- Anode spot is more pronounced with moving cathodes
- Liquid material on cathode is not smooth due to the cathode spots
- All this phenomena influence the burn off rate

Conclusion and open questions

- It makes a measurable difference whether the cathode is the moving or fixed contact
- Cathode spots on molten contact material play an important role
- Differences are measurable even at lower opening speeds down to 1 m/s
- The phenomenas are not fully understood
- As far as we know there is no significant influence on switching performance



Contact

Andreas Lawall

Development Vacuum Interrupters
SI EA R&D OC VI
Rohrdamm 88
13629 Berlin
Germany

Mobile +49 172 9715557

E-Mail Andreas.Lawall@siemens.com